

VSIPPTZKBV2



Product Overview

The IP PTZ control keyboard is compatible with all VIP Vision, Securview and Watchguard PTZ cameras over a network.

- Control a variety of PTZ cameras and DVRs with this PTZ keyboard
- Features RS485, RS422, USB, RS232 & RJ45 connections
- · Three dimensional joystick control of PTZ functions
- Preset position, auto scan, auto pan, auto tour & pattern control
- 3.2" on-keyboard LCD with user menu and operation/ procedure tips
- Interfaces to PTZ domes and DVR/NVR via Network mode and Direct mode
- Network mode: Control via RJ45 using IP address and ports
- Direct mode: Control via RS232/RS485 w/ protocols below
- DVR: DH2 / Camera protocols: DH-SD, PELCO-D/-P/-D1/-P1
- Can connect and control via VIP Vision SmartPSS through USB



Your VIP Vision professional: