

## EMAIL SETUP

1. Go to **MAIN MENU**, select **NETWORK** under setting, then **EMAIL**.
2. Click Enable at the top of the Email window.
3. Enter your SMTP server and port.

Alternatively, you can google your email provider with SMTP, eg, "bigpond smtp settings"

PROVIDER	SMTP SERVER	PORT
Gmail	smtp.gmail.com	465
Yahoo	smtp.mail.yahoo.com	465
Hotmail	smtp-mail.outlook.com	587
Telstra	smtp.telstra.com	465

4. Enter your email address and password.
5. Input a different address for sender and receiver as they cannot be the same.
6. Enter an email subject.
7. Select encryption type. If you used Port 465 then use SSL, if you used 587 use TLS.

Interval: Changes the interval at which emails will be sent at.

Health: Test email to check network connectivity.

Attachment: Will allow snapshots to be sent with notification email if enabled.

