

# **2-Wire Controller**

## **User's Manual**



# Foreword

## General

This manual introduces the installation, functions and operations of the 2-wire controller device (hereinafter referred to as "the Controller"). Read carefully before using the device, and keep the manual safe for future reference.

## Models

VTNC1003C

## Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 <b>DANGER</b>	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 <b>CAUTION</b>	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 <b>TIPS</b>	Provides methods to help you solve a problem or save time.
 <b>NOTE</b>	Provides additional information as a supplement to the text.

## Revision History

Version	Revision Content	Release Time
V1.0.4	Revised the network diagram.	March 2023
V1.0.3	Revised power supply demand.	February 2023
V1.0.2	Revised technical standard description.	January 2023
V1.0.1	Revised production overview.	December 2022
V1.0.0	First release.	October 2022

## Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

## Interface Declaration

This manual mainly introduces the relevant functions of the device. The interfaces used in its manufacture, the procedures for returning the device to the factory for inspection and for locating

its faults are not described in this manual. Please contact technical support if you need information on these interfaces.

## About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

# Important Safeguards and Warning

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, and comply with the guidelines when using it.

## Operation Requirements



- Check whether the power supply is correct before use.
- Do not unplug the power cord on the side of the device while the adapter is powered on.
- Operate the device within the rated range of power input and output.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Do not drop or splash liquid onto the device, and make sure that there is no object filled with liquid on the device to prevent liquid from flowing into it.
- Do not disassemble the device without professional instruction.

## Installation Requirements



**WARNING**

- Do not connect the power adapter to the device while the adapter is powered on.
- Strictly comply with the local electric safety code and standards. Make sure the ambient voltage is stable and meets the power supply requirements of the device.
- Do not connect the device to two or more kinds of power supplies, to avoid damage to the device.
- Improper use of the battery might result in a fire or explosion.



- Personnel working at heights must take all necessary measures to ensure personal safety including wearing a helmet and safety belts.
- Do not place the device in a place exposed to sunlight or near heat sources.
- Keep the device away from dampness, dust, and soot.
- Install the device on a stable surface to prevent it from falling.
- Install the device in a well-ventilated place, and do not block its ventilation.
- Use an adapter or cabinet power supply provided by the manufacturer.
- Use the power cords that are recommended for the region and conform to the rated power specifications.
- The power supply must conform to the requirements of ES1 in IEC 62368-1 standard and be no higher than PS2. Please note that the power supply requirements are subject to the device label.
- The device is a class I electrical appliance. Make sure that the power supply of the device is connected to a power socket with protective earthing.

# Table of Contents

<b>Foreword</b> .....	I
<b>Important Safeguards and Warning</b> .....	III
<b>1 Product Overview</b> .....	1
<b>2 Structure</b> .....	2
<b>2.1 Front Panel</b> .....	2
<b>2.2 Real Panel</b> .....	3
<b>3 Network Diagram</b> .....	4
<b>4 Technical Standard</b> .....	6

# 1 Product Overview

The 2-wire controller is used to isolate power supply and signal, and therefore to reduce the system signal transmission intervention from the input power port.




We recommend using the power supply provided with the device in the package. If you solely purchased the device without its power supply, then please make sure that the power supply you intend to use was certified by our company.

## 2 Structure


### 2.1 Front Panel

Figure 2-1 Front panel (unit: mm [inch])



## 2.2 Real Panel

Figure 2-2 Rear panel (unit: mm [inch])



# 3 Network Diagram



- The two wires connected to the positive and negative terminals of OUT cannot be short-circuited.
- Line termination terminal and branch terminal are optional in this scenario.

Figure 3-1 Network diagram (without line termination terminal and branch terminal)

## 1 VTO + 1 VTH Scenario





Figure 3-2 Network diagram (with line termination terminal and branch terminal)

**1 VTO + 1 VTH Scenario**



# 4 Technical Standard

Table 4-1 Technical standard for 2-wire controller

<b>Parameter</b>	<b>Specification</b>
Product Dimensions	65.2 mm × 46.2 mm × 23.2 mm (2.57" × 1.82" × 0.91")
Power Supply	48 VDC/0.9 A
Operating Temperature	-10 °C to +55 °C (14 °F to +131 °F)
Operating Humidity	10 %–95 % (RH)
Operating Altitude	0 m–3,000 m (0 ft–9,842.51 ft)
Power Consumption	3.5 W
Net Weight	0.048 kg (0.11 lb)
Gross Weight	0.13 kg (0.29 lb)
Max. Normal Load	The maximum normal load with 1 VTO, 5 VTHs, and 2 VTHs, each load 0.2A.